

How to Convert from VHS to Mini DV

1. **Load cassettes**
2. **Select dubbing direction**
 - a. Press ←
3. **Set tape speed w/Remote**
 - a. Press **DV**, then press **SP/LP**
4. **Locate the Start Point on the VHS deck**
 - a. Press **S-VHS**
 - b. Press **Play (▶)** to start playback
 - c. Press **Pause (⏸)** to pause playback a little before the start point
5. **Prepare the DV Deck for dubbing**
 - a. Press **DV**
 - b. Press and hold **Pause (⏸)** and press **REC (●)** so that the DV deck enters the Record Pause mode.
 - i. VHS playback indicator and DV recording indicator light
6. **Start Dubbing**
 - a. Press **START**
7. **Pause Dubbing**
 - a. Press **Start**
8. **End dubbing**
 - a. Press **Stop (■)** to stop recording on the DV deck. Then press **S-VHS** and press **STOP (■)** to stop playback on the VHS deck

